


TO HIHAT PEDAL
POTENTIOMETER

DO NOT CONNECT

COM + BV 0V



CAPACITORS WITHOUT VALUE ARE 100NPF